


TABLE TENNIS TABLE INSTRUCTION

Model No.: OUTDOOR 2000

Assembly Instructions

Carefully lay both table tops flat and face down on a soft surface. Unlock and unfold pre-assembled table top, slide 'T' rolling leg into designated position and ensure marking tape lines up on each side, see figure 1.



Preparation for use


1. Open the carton and check to ensure all accessories and fittings are complete.
2. Install 'T' rolling leg according to figure 1 above.
3. Tighten all screws and turn table up the right way ready for use.

Care and Maintenance for use of your Table

1. Two pieces of table top have to be separated before folding or opening.
2. This table can be used outdoors.
3. Do not beat on surface of table with paddle.
4. Do not place hot goods on table top.
5. Do not place heavy goods on table to avoid distortion.
6. Do not use table for any other exercise other than table tennis.
7. Do not move table around quickly on rugged ground.

Operation Method


Security Lock Operation



Release the lock before opening the Table Tennis Table and lock it prior to folding the table.

Leg Hinge


When in use When Collapsing



Straighten hinge when using table and collapse hinge to fold table.

Wheel Operation

Locked Unlocked



Lock wheel tightly when using table and unlock for moving and storing.

Height Adjusting Method





Figure 5

The wheel height can be adjusted to a maximum of 15mm.

To adjust the table height at wheel, screw part A (as seen in figure 5) anti-clockwise to raise the table, and Part B clockwise to lower it.



The foot height can also be adjusted to a maximum of 15mm.

To adjust table height at the foot, screw foot anti-clockwise to raise the table, and clockwise to lower it.

All feet can be adjusted slightly to ensure a level playing surface.